

INNOVATION AT WORK

Connecting Visionaries in Radiation Safety, Science and Industry

Conrad Orlando Resort, FL – July 28th – August 1st



Real World Application for Continuous Spectroscopic Monitoring

Peter D'Agostino and Frazier Bronson

Product Line Manager / Scientific Director

Mirion Connect | Annual Users' Conference 2025 Orlando, Florida



Agenda

- Overview of CSM and the Data Analyst[™]
- What's new in the Data Analyst™since MC24
- Discussion of multiple user Applications
- Questions and Discussion
 - How can we help you with your CSM needs?



CSM with Data AnalystTM






What is CSM?



- Automated counting at defined intervals
- Enabled by the Data Analyst
- Also remotely triggered analyses
- Data Analyst is a core building block for advanced online monitoring systems, providing real-time nuclide activity results.
- Runs continuously recording the data locally as well as transmitting live data to real-time monitoring systems.
- Can be embedded within larger systems such as stack monitors and scanning systems, or be used on mobile platforms like drones and robots
- Automated counting & analysis of a gamma spec system, 24/7
- Ability to view results & trend plots live
- See alarms immediately



Basic Components of CSM






Sample Counting vs. Continuous Spectroscopy



Traditional Sample Counting

- Calibrate detector for specific container geometries
- Collect several samples per day from sampling points
- Put sample in shield & count, results analyzed
- Review results on report
- Publish/use reports, decide if there's an issue






Continuous [or triggered] Spectroscopy

- Measurement is done In-situ
- Calibrate via ISOCS
- Point detector at object to be measured
- Automated counting & analysis, 24/7
- · View results live & view trend plots & utilize
- · See alarms immediately


The Advantage of Continuous Monitoring

Manual Sampling is much less frequent & can miss events



Workflows

- Aggregate & analyze measurement data at preset interval(s)
- Multiple Workflows can be used simultaneously





ALL NEW Data Analyst Interface


Setup, Config, Operations

> Alarm, Fault indicators

Dose & Count Rate Meters

NID Results

MIRION 25





Data Time Plot for Dose, and Nuclide Activity

Innovation at Work

© 2025 Mirion Technologies. All rights reserved.

What is included in DA-PRO







Includes DA-PRO software preinstalled

What's New since MC24?





Data Analyst Software Version 2.0

Released Summer 2025



MIRION 25

Connect 25

Annual Users' Conference

- Main update is the all new HTML5 based user interface
 - Compatible with all major web browsers (Chrome, Edge, Safari, etc)
 - No need for standalone desktop applications
 - Provides for remote access from any device



Innovation at Work

New hardware support

- DSA-LX MCA
- Aegis MCA and HPGe Portable
- MicroGe
- Spir-Explorer MCA and can also double as a Dose device
- RDS-32 Dose device









New features



- Previously feature only available with Horizon
- Monitors Activity, Energy, FWHM
- Up to 2 energies
- Alerts and Alarms can be generated
- Workflow can be Triggered [for conventional check source operation] or Continuous using built-in low activity source [see later slides]
- Dynamic Workflow enhancements
 - User enters Minimum, Incremental, and Maximum count time values
 - Assays are done after Minimum time, and after each incremental time.
 - Count terminated based upon "MDA to meet" value for selected nuclides
- Software Triggering implemented
- Linux Mint 22 now supported and installed for network systems





Legacy interface

Adobe Flash & Adobe-AIR









- The legacy Data Analyst UI is built using Adobe Flash technology
- Still available in the DA 2.0 software distribution for existing systems that already have documentation/training based on the Flash based UI
- Flash Player no longer supported by Adobe as-of Dec 31, 2020
- Flash Players have been removed or disabled in most major browsers
- An alternative is to use Adobe-AIR to run the DA User Interface
- We include the installable DA Adobe-AIR application on our software CD
- This application is the same software that runs in the browser but needs to be installed on the client computer
- Adobe-AIR runtime is now maintained by HARMAN (Samsung) and can be downloaded from their website airsdk.harman.com/runtime

Applications





Continuous or Triggered Spectroscopy using the Data Analyst








NPP in-situ CZT system




Plutonium






Robot ground and floor. dual Nal




Pipe process monitor Nal



Tank monitor, dual CZT x 4

Fuel cask monitor

CZT detector



Fuel Rod Scanner **HPGe**



Particulate, Iodine, Gas monitor CZT [left] HPGe [right]



BWR primary coolant monitor, CZT



Lu177 assay, CZT


Innovation at Work

Excavation © 2025 Mirion Technologies. All rights reserved. bucket monitor

Underwater Monitoring – LaBr and HPGe in Spent Fuel Pool

- LaBr3 detector and Osprey MCA in housing
 - 75' Ethernet cable
 - Data Analyst and PC remote
- HPGe 25% Relative Efficiency SEGE
 - CP5 electrical cooler
 - 98' composite cable
 - Lynx MCA, Controller, Data Analyst, and PC all remote
- ISOCS Characterization both detectors
- ISOCS infinite thickness calibration for Fuel Pool water
 - Customer can do underwater object calibrations using standard ISOCS









Lu-177 assay system at Bruce Power

- Targets are enriched Yb-176, 1-2 week activation, 1d decay
 - Arr Yb-177 [T½ = 1.9hr] produced; decays to Lu-177 [T½ = 6.7d]
- Sample assayed at 40cm away inside 15cm thick tungsten box
 - Estimated activity at time of measurement is ~70 Ci [3E12 Bq]
 - About 50 more samples of similar activity are waiting in the queue only 20 cm and away behind 15cm of Tungsten
- Heavily attenuated CZT detector
- Custom Touch screen PC for operator
 - 2 Touch screen triggered Workflows
 - One for QC source and Background, One for Targets
- Custom software consolidates all the data. loads into database, and generates shipping document
- check source



Selections Class Analysis (NO Assay Systems 194, 202)



Innovation at Work


© 2025 Mirion Technologies. All rights reserved.


2.5 years of QC data on Lu177 system


- CZT detector and Cs-137 check source
- Detector ~50' away on USB-Ethernet-USB cable
- In hot [thermal] area; ~40C
- 275 measurements of check source
 - Before and after each shipment batch
- Net counts warning/alarm to operator
 - very stable; 1 outlier, repeat count was good
- FWHM very stable
 - 1 outlier same as above
- Energy changes, but not enough to change activity
 - Human error; after battery change the incorrect energy calibration was entered



Issue uncovered in DA Area Engine: minor change in energy coefficient caused incorrect ROI settings in Area engine; not new issue, fix available if needed








Pipe Assay Continuous Monitoring Systems

- This is the most frequently discussed system
- They are quite easy to implement, either by us or by a knowledgeable user
- Easiest and least expensive:
 - CZT system using standard shield
 - Easy to set up and deploy
 - OK for moderately complex nuclide mix
- Most Sensitive:
 - Nal system; 3x3 LED-stabilized detector
- Best for Complex Situations
 - HPGe system with CP5 cooler
 - Wide dynamic range, Low energy, ...





NPP in-situ CZT system




X-energy Pebble Bed Reactor BurnUp Monitoring System - BUMS


- 200 MW thermal, 80 MW electrical
- 6cm diameter pebbles contain the fuel
 - TRISO TRI-structural ISOtropic
 - 18,000 TRISO particles in each pebble
- 220,000 pebbles in reactor at same time
- Helium flows around the pebbles to extract heat
- Continuous refueling for 60 year operation
- Pebbles come out of Reactor to be assayed in BUMS
 - Most go back into Rx until max BU reached
 [160 GWd/t]
 - Max utilization of fuel; minimum fuel cost



https://youtu.be/Aause IxFQRE








Mirion Project

- 2+ years in a 5y project to Design BUMS & Build Prototype
 - HPGe Detector & Collimator design done
 - Prototype Algorithm developed
 - Detailed design now underway
 - Much interface with customer as the Rx design evolving
- Shielding design complicated.
 - Many pebbles close causing high background
 - Gamma and neutron background considerations
 - Equipment high-dose lifetime considerations
- Data Analyst key to success
 - Triggered mode for pebbles
 - Continuous QA & detector parameter monitoring



Key Features used and Items added to Data Analyst for BUMS


- Standard capabilities used:
 - Post-NID script to determine pebble type and burnup
 - Standard capability in the DA and now in Genie 4.1
 - Triggered mode for Pebble, and simultaneous Continuous mode for Continuous-QC
 - Dynamic Workflows counts just long enough for accurate decision
 - Count to MDA standard, adding count to precision
- New features: can be used on other projects when needed
 - OPC-UA data/result outputs compatible with PLCs
 - Vital Supervisory software to replace Horizon
 - Remote triggering of differing analysis operations modes
 - Watchdog and Heartbeat outputs
 - Time synchronization of 1 or more DAs with external clock




Projects using Data Analyst with Continuous QC



Primary Coolant Monitor, HPGe




Pipe process monitor Nal




Continuous Monitors


Sample Assay system can also use it







Low activity to not interfere with sample assays Long count Workflow – e.g. 24hr








Innovation at Work


Example - QA data from Primary Coolant Monitoring system

- HPGe system in operating NPP for 6mo
- Thorium 2614 keV line used
 - Activity [efficiency]
 - Energy [gain]
 - FWHM [detector quality
- Activity stable
 - Changes are from equipment reconfiguration
 - Most important QC parameter
- FWHM stable; ~2.3 keV
 - Detector quality indicator
- Gain showed changes, but
 - Always within QC limit of 0.5 FWHM
 - Nuclide ID good until about 1.0 FWHM
 - Much of Gain changes due to temperature changes
- During COVID, otherwise would have adjusted the gain










Notification to Data Analyst User for Alerts and Alarms

- Horizon Users
 - Displays live DA output
 - Tests for Hi & Lo QC Limits
 - Activity, Energy, FWHM
 - 1-3 single-line Nuclides
 - On-screen Alert & Alarms
 - Sends text messages upon Alarm
- Data Analyst users [new feature]
 - QQC Quick Quality Control
 - Tests for Hi & Lo Limits
 - Activity, Energy, FWHM
 - 1-2 single-line Nuclides
 - Activates Alert and Alarm flags
 - LED on-screen indicators [if viewing]
 - GPIO signals for Alert and Alarm





Waste Management 2026 Call for Papers

- Abstracts are due August 22
 - Papers around end of November for 1st draft
 - Meeting March 8-12, Phoenix AZ
- Sasha Philips and Frazier Bronson are the coordinators of Track 3 Waste Characterization
- We are responsible to solicit papers this it!
- It is a Great meeting for those of us involved, now or in the future, with D&D and ER projects





WM2026 THEME:

EFFICIENT AND INNOVATIVE NUCLEAR MATERIALS AND TECHNOLOGY SOLUTIONS



CALL FOR PARTICIPATION PRESENTER, EXHIBITOR, SPONSOR & ATTENDEE!

WM2026 - THE PREMIER AND ONE OF THE MOST ANTICIPATED CONFERENCES WITH SUPERIOR TECHNICAL TRACKS AND NETWORKING ON RADIOACTIVE WASTE AND MATERIAL MANAGEMENT.

Elevate your expertise at WM2026, the S2nd annual Waste Management Symposia (WM). This dynamic forum unites global experts to drive safe, cost-effective solutions for handling radioactive materials and decommissioning nuclear facilities. Join a powerful global network of 3,000 attendees, 900 organizations, 30 countries, and 200 exhibitors—to exchange insights, tackle key challenges, and explore groundbreaking solutions.

Explore cutting-edge research, development, and operational insights across 12 specialized tracks, featuring discussions on critical topics like Used Fuel, D&D, Procurement and Contracting, Safety, Legacy Site Cleanup worldwide, and NRC, DOE initiatives. Engage in exclusive panel and paper sessions spotlighting our theme, "Efficient and Innovative Nuclear Materials and Technology Solutions," and this year's Featured Country - Finland and Featured US DOE Site – Hanford, Washington.

Discover the full WM2026 Topic Listing at www.wmsym.org. Be part of the conversation that drives progress!

MARCH
2026

PHOENIX
CONVENTION
CENTER

wmsym.org
#wmsym2026

Questions? Discussion

How can we help?





Thank you



